

Installation Case Study

2015 Mercedes Benz Springer 2500

- UB1+UB3: Replaced the factory bump stops with Universal Rubber Bump Stops

(Do not Copy) These instructions are part of an Installation manual that is under Copyright Protection by RubberShox®/DuraSHOCK®



If you order wrong size buffers to install on your vehicle. Please contact us at info@rubbershox.com immediately. We will arrange replacement buffers for you.