

# Installation Case Study

## 2013 Ram Promaster 1500

- Replaced the factory bump stops with Universal Rubber Bump Stops **UB1223**

(Do not Copy) These instructions are part of an Installation manual that is under Copyright Protection by RubberShox®/DuraSHOCK®



**Before**



**After**



If you order wrong size buffers to install on your vehicle. Please contact us at [info@rubbershox.com](mailto:info@rubbershox.com) immediately. We will arrange replacement buffers for you.