

Front coil springs: DuraTPE® Plus Series AP, Rubber Block Booster Series RB275-2-175

Rear coil springs : DuraTPE® Plus Series A & BP Ground Lifting Height : ~1"+



1. Jack up car, measured ~ 2.5" Gap



2. Choose A+ , Inner Groove is 2.5", match to Gap 2.5"



3. Spray lots of WD40 both side for easy install



4. Cut off bottom side inner groove for easy insertion




5. Choose the biggest coil gap to begin insert from top groove sit inside groove, then bottom groove pushing in. Make sure top & bottom groove bot sit on coil spring



Front coil springs : DuraTPE Plus AP / Rubber Block Booster RB275-2-175 installed



Rear coil springs : DuraTPE Plus A / BP installed



Raised ~1"+ ground clearance, Ride Stiffer reduce sway caused by old rear struts