

Installed Items : RubberShox Universal Bump Stops Model: UB1+UB2 and Z1-UBS bracket

IMPORTANT NOTICE: RUBBERSHOX INSTALLERS SHOULD APPLY COMMON AUTOMOTIVE SAFETY PRACTICES WHEN RAISING, LOWERING AND WORKING ON VEHICLES, ALWAYS WEARING SAFETY GLASSES, USING BOTH HYDRAULIC JACK AND JACK STAND DURING THE INSTALLATION. We recommend that this installation be done by a professional or person with auto mechanical knowledge. RubberShox Universal Bump Stops are designed to work with original factory springs only. These instructions are general guide line. RubberShox assumes no liability for actual installation process. Rubbershox does not recommend exceed the maximum load recommended by vehicles manufacturer (GVWR)



RubberShox Universal Bump Stops Model: UB1+UB2 and Z1-UBS bracket



Difference between RubberShox UBS Bump Stop with factory original equipment.



2021 Toyota Tacoma TRD sports V6 4 wheels drive.



Ground to rear wheel fence, 36.5"



After loading 1,180 Lbs. weight. The truck slant to end rear.



Ground to fence height around 33".

Installation Procedure:

Loose the original bolts for the clamps and take out the original bump stop replace with RubberShox® UBS UB1+UB2 with Z1-UBS bracket.

Note: After replacing with the UBS bump stop and tighten the bolts for the clamp. You should make sure you tight up each screen with couple turns equally until it meets the factory require torque (refer to your vehicle user manual). Make sure you do not tight one screw too much and tilt the clamps.



After replaced with UB1+UB2 or our UBS series bump stop. The truck looks flat from front to back with the rear height 35".