

**WARNING:** Customers require common automotive safety practices during the installations, we recommend installation be done by a professional mechanical knowledge. RubberShox hold no liability for actual automotive safety practices.

if you order wrong size buffers to install on your vehicle.  
 Please contact us at **info@rubbershox.com** immediately. We will arrange replacement buffers for you.

UB1A is specially designed for Mercedes Benz Sprinter Van.  
 It needs combine with UB3A to complete a whole Bump Stop sets. You can add UB2 in between to reach desired support.

Model #	Use
UB1A+UB3A	Light to medium load cargo
UB1A+UB2+UB3A	Constant medium load cargo
UB1A+UB2X2+UB3A	Constant heavy load or Sprinter Camper

**Tools needs:**

Breaker Bar, Drive Socket Set, Torque Wrench, Jack Stand, Lift, Wheel Stop, Safety Goggle, WD-40



Designed for Mercedes Benz Sprinter Van

**Installation Procedure:**

1. Jack Up your Vehicle , please be sure follow standard Vehicle Safety Prostatic (extra Jack Stand)
2. Remove OE bump stop & Install UB1A (see Fig.1)
3. Glue & Attach other Modular (UB2/UB3A) to UB1A (Already Installed)
4. Manual Compress all module into one unit
- 5. Slowly Remove Hydraulic Jack , make sure all module join well and UB3A sit well on rear Axial prior complete release Jack**

**Tips:** constant heavy load weight (ex. RV), recommend UB1A23A or even UB1A223A. Not heavy load recommends to UB1A3A or UB1A23A



**Fig:1**

UB1A Replace to OE Bump Stop 2016 Mercedes Benz Sprinter 2500 Rear Suspension (Require UB2 & UB3A add-on depend on your load weight.)