

**WARNING:** Customers Customers require common automotive safety practices during the installations, we recommend installation be done by a professional mechanical knowledge. RubberShox hold no liability for actual automotive safety practices.

if you order wrong size buffers to install on your vehicle.  
 Please contact us at **info@rubbershox.com** immediately. We will arrange replacement buffers for you.

UB3A is specially designed for Bump Stops installed on vehicle's frame to hit on axels, like Ford F150/250, Mercedes Benz Sprinter.... etc. It needs UB1 or UB1A with UB2 to form a desired Bump Stops height for your vehicle.  
 Used include rubber glue to attach to UB2, UB1, or UB1A

Model #	Use
UB1A/UB1+UB3A	Light to medium load
UB1A/UB1+UB2+UB3A	Constant medium load/towing
UB1A/UB1+UB2X2+UB3A	Constant heavy load/towing, converted camper

