

## How to Select & Install RubberSho® Block Booster to Enhance your suspension system, Driving stability and Raise Ground Clearance




Fig 1




Fig 4




Fig 3




Fig 3a



Scan for Official RubberShox Website

(Table 2) Series	RubberShox Block Booster Model	Size (2pcs for L & R Front/Rear Coil Spring)	Coil Spring Gap Edge Distance
Block Booster	<b>RB45-3-25</b>	4.5" x 3" x 2.5" x 2pcs	4.5" or 3" or 2.5"
Block Booster	<b>RB35-25-125</b>	3.5" x 2.5" x 1.25" x 2pcs	3.5" or 2.5" or 1.25"
Block Booster	<b>RB275-2-175</b>	2.75" x 2" x 1.75" x 2pcs	2.75" or 2" or 1.75"
Block Booster	<b>RB2-15-125</b>	2" x 1.5" x 1.25" x 2pcs	2" or 1.5" or 1.25"
Block Booster	<b>RB125-1-1</b>	1.25" x 1" x 1" x 2pcs	1.25" or 1" or 1"

1. Lift & Jack up your vehicle (make sure tires are not touching ground) – Fig 1
2. Measure your Coil Spring Gap (ex. 64.7mm / 2.5") – Fig 1
3. Ref. to Rubber Block Table, Select the closest height (no greater than measured spring gap distance) – Table 2
4. Choose RB45-3-25, RB35-25-125 or RB275-2-175, as 2.5" or 2" is the closest - Table 2
5. Installed RB45-3-25, RB35-25-125 or RB275-2-175 (paired with CSBPro-AP) – Fig 3/3a/4
6. Raise up Front Suspension Ground Clearance around 2.5"
7. We strongly suggest using Zip-Tie to secure Rubber Block to Coil Spring
8. Fig4 shown extra RB275-2-175 block installed on smaller coil spring gap (2") under the RB35-25-125 (2.5" side). Different size blocks can be installed on various gap distances on the same coil spring.