

WARNING: Customers require common automotive safety practices during the installations, we recommend installation be done by a professional mechanical knowledge. RubberShox hold no liability for actual automotive safety practices.

if you order wrong size buffers to install on your vehicle.
 Please contact us at **info@rubbershox.com** immediately. We will arrange replacement buffers for you.

Installed Vehicle:

2015 Mercedes Benz Sprinter 2500 / RoadTrek SS Agile (Fig 1)

Tools needs:

Breaker Bar, Drive Socket Set, Torque Wrench, Allen Wrench, Jack Stand, Lift, Wheel Stop, Safety Goggle, WD-40



Fig.1



Installation Procedure:

1. Jack Up your Vehicle, please be sure follow standard Vehicle Safety Prostatic (Prefer Extra Jack Stand)
2. Remove OE bump stop & Install UB1A
3. Choose your preferred sizes of RubberShox Bump Stop(UB1A3A or UB1A23A or UB1A223A – Fig2).

UB1A3A	Occasionally Heavy Loading – Sprinter Van
UB1A23A	Constant Light to Medium Loading, or Light Towing – Sprinter Van
UB1A223A	Constant Heavy Loading, Camper or Heavy Towing

4. Example of UB1A223A below
5. **Tips:** Constant heavy load weight (ex. RV), recommend UB1A223A or UB1A23A. A UB1223A. Constantly contact to Rear Axial support a heavier load and a higher ground clearance. But also result to bumpy drive if not heavy load (non-RV)
6. Glue & Attach Modular together (UB2 / UB3A) to UB1A (Already Installed)
7. Slowly Remove Hydraulic Jack, make sure each module join well with Glue and UB3A sit on center rear Axial, prior complete release Jack
8. Take a test drive and make sure all items contact well and drive as expect.

Note:

- RubberShox always recommend finding vehicle professional installer for installation
- This item is not to increase your vehicle load weight, but to support a comfort drive, you are welcome to contact to RubberShox / DuraSHOCK Tech support, please email to service@rubbershox.com / service@durashock.com



Fig.2



UB1A Replace to OE Bump Stop 2015 Mercedes Benz Sprinter 2500 (RoadTrek SS Agile) Rear Suspension (Require UB2 & UB3A Module)



RubberShox UB1A223A Installed under 2015 Mercedes Benz Sprinter 2500 (2016 RoadTrek SS Agile) Rear Suspension



Showing OE Bump Stop vs. Other Brand vs. UB1A223A (2015 MB Sprinter 2500 / 2016 RoadTrek SS Agile)



RubberShox UB1A223A vs. OE Bump Stop



RubberShox UB1A3A vs. Other Brand vs. OE Bump Stop



RubberShox UB1A23A vs. OE Bump Stop



Showing OE Bump Stop vs. Other Brands vs. RubberShox Natural Rubber UB1A223A

Watch Video on www.rubbershox.com



2015 Mercedes Benz, Sprinter 2500 (2016 Roadtrek Agile)
 Rubber Bump Stop UB1A223A installed to Rear Suspension
 Ground Lifting Height : + 2.3" with UB1A223A (+1.5" with UB1A23A)